

```
In[ ]:= ClearAll["Global`*"];
```

```
In[ ]:= $Version
```

```
Out[ ]:= 12.3.0 for Mac OS X x86 (64-bit) (May 10, 2021)
```

```
In[ ]:= SetDirectory[NotebookDirectory[]];
```

Crossed-polarization (CP) optical microscopy intensity calculation

A. Input


B. Optical properties

C. Light properties after passing through a single CNC (add figure)

- Electric field, intensity and polarization angle as a function of the polarization angle with respect to the CNC angle

(* Supplementary Figure 8a *)

$E_p = E_{\parallel}$, $E_s = E_{\perp}$



```

In[ ]:= (*ε= ~0 *)
ε = 10-9;
θ = ε(*deg*);

(*Incident beam Ep0, Es0, Ip0, Is0*)
Ep0[φ_] := 1 Sin[φ * (π / 180)];
Es0[φ_] := 1 Cos[φ * (π / 180)];
Ip0[φ_] := Ep0[φ]2;
Is0[φ_] := Es0[φ]2;

(* Output beam- Ep1, Es1, Ip1, Is1 after a single CNC *)
Ep[φ_] := Ep0[φ] * t123p[[8]]; (*[[8]]=600nm *)
Es[φ_] := Es0[φ] * t123s[[8]]; (*[[8]]=600nm *)
Ip[φ_] := Ep[φ] * Conjugate[Ep[φ]];
Is[φ_] := Es[φ] * Conjugate[Es[φ]];

(* Output beam- ψ, (ψ-φ) (φ dependence) *)
ψ[φ_] := Piecewise[{
  {ArcTan[√Ep[φ] * Conjugate[Ep[φ]] / √Es[φ] * Conjugate[Es[φ]]] *  $\frac{180}{\pi}$  - 180,
    φ < -90},
  {ArcTan[√Ep[φ] * Conjugate[Ep[φ]] / -√Es[φ] * Conjugate[Es[φ]]] *  $\frac{180}{\pi}$  + 180,
    φ > 90},
  {ArcTan[√Ep[φ] * Conjugate[Ep[φ]] / √Es[φ] * Conjugate[Es[φ]]] *  $\frac{180}{\pi}$ , φ > 0},
  {ArcTan[√Ep[φ] * Conjugate[Ep[φ]] / -√Es[φ] * Conjugate[Es[φ]]] *  $\frac{180}{\pi}$ , φ > -90}
}] (* ψ=tan-1[E||/E⊥] - Equation 3 *)

(*Output beam |Etot| and Itot*)
Et[φ_] := √Ep[φ] * Conjugate[Ep[φ]] + Es[φ] * Conjugate[Es[φ]];
(* |Etotal| = √E||*E||*+E⊥*E⊥* - Equation 4 *)
It[φ_] := Et[φ] * Conjugate[Et[φ]];

(*transmission coefficient*)
tt[φ_] := Et[φ] / 1;

```





```


In[ ]:= (*check plots*)
{Plot[ψ[φ], {φ, -180, 180}, PlotRange → {{-180, 180}, {-180, 180}},
  Ticks → {Table[30 i, {i, -12, 12}], Automatic},
  GridLines → {Table[45 i, {i, -4, 4}], {-90, -45, 45, 90}},
  PlotLegends → Placed[{"ψ"}, {0.7, 0.9}], PlotStyle → {Blue},
  AxesLabel → {"Azimuth angle(φ)", None}, ImageSize → 500, AspectRatio → 1 / 2,
  LabelStyle → {FontFamily → "Arial", FontSize → 15, Black}},
Plot[{ψ[φ] - φ}, {φ, -180, 180}, PlotRange → {{-180, 180}, {-0.005, 0.005}},
  Ticks → {Table[45 i, {i, -12, 12}], Automatic},
  GridLines → {Table[45 i, {i, -12, 12}], Automatic},
  PlotLegends → Placed[{"ψ-φ"}, {0.9, 0.85}], PlotStyle → {Blue},
  AxesLabel → {"Azimuth angle(φ)", None}, ImageSize → 500, AspectRatio → 1 / 2,
  LabelStyle → {FontFamily → "Arial", FontSize → 15, Black}}
  (* Supplementary Figure 8b *)
}

{Plot[Et[φ], {φ, -180, 180}, PlotRange → {{-180, 180}, All},
  Ticks → {Table[30 i, {i, -12, 12}], Automatic},
  GridLines → {Table[45 i, {i, -12, 12}], Automatic},
  PlotLegends → Placed[{"|Et|"}, {0.84, 0.87}], PlotStyle → {Blue},
  AxesLabel → {" Azimuth ang(φ)", None}, ImageSize → 500, AspectRatio → 1 / 2,
  LabelStyle → {FontFamily → "Arial", FontSize → 15, Black}}
  (* Supplementary Figure 8c *)
Plot[It[φ], {φ, -180, 180}, PlotRange → {{-180, 180}, All},
  Ticks → {Table[30 i, {i, -12, 12}], Automatic},
  GridLines → {Table[45 i, {i, -12, 12}], Automatic},
  PlotLegends → Placed[{"It"}, {0.84, 0.87}], PlotStyle → {Blue},
  AxesLabel → {" Azimuth ang(φ)", None}, ImageSize → 500, AspectRatio → 1 / 2,
  LabelStyle → {FontFamily → "Arial", FontSize → 15, Black}}}

Plot[tot[φ], {φ, -180, 180}, PlotRange → {{-180, 180}, All},
  Ticks → {Table[30 i, {i, -12, 12}], Automatic},
  GridLines → {Table[45 i, {i, -12, 12}], Automatic},
  PlotLegends → Placed[{"t_tot"}, {0.84, 0.87}], PlotStyle → {Blue},
  AxesLabel → {" Azimuth ang(φ)", None}, ImageSize → 500, AspectRatio → 1 / 2,
  LabelStyle → {FontFamily → "Arial", FontSize → 15, Black}}

```





D. 100 CNC angle generation for the five CMF organizations: crossed-polylamellate, random, helicoidal (10°), uniaxial, and biomodal.

E. Light properties after the 100 CNC organizations - Loop1 for each organization

```
In[*]:= φi = 0; (* the initial polarization direction of the incident beam w.r.t. y-axis *)
(*0 deg was chosen as an example - Supplementary Figure 8 *)
φi = φi + ε; (* ε is a small number, 10-9 *)
```

1) Cross-polylamellate

Storage

Loop

```
In[*]:= For[p = 1, p < n + 1, p++,

  φbtn[[p]] = ψy[[p]] - φcl180Norm[[p]]; (* convert axis: From y-axis to CNC normal *)
  ψres[[p]] = ψ[φbtn[[p]]]; (* result of rotation in CNC normal axis*)
  ψy[[p + 1]] = ψres[[p]] + φcl180Norm[[p]];
  (* back to y-axis system*) (*F180 is for *)

  dψ[[p]] = ψres[[p]] - φbtn[[p]]; (* (ψafter - ψbefore) in CNC axis *)

  ttot[[p]] = tt[φbtn[[p]]];
  Etot[[p + 1]] = Etot[[p]] * ttot[[p]]; (* energy loss as passing through *)

  dψ2[[p]] = ψy[[p + 1]] - ψy[[p]];
  (* (ψafter - ψbefore) in CNC axis. How much rotation @ each CNC*)
]
PI = (Etot[[n + 1]] * Sin[(ψy[[n + 1]] - φ1) *  $\frac{\pi}{180}$ ])2; (* I = (|Etotal| * sinψ)2 - Equation 5 *)
```

Check plots and final intensity (Supplementary Figure 8e,f here)



```




In[ ]:= {ListPlot[φcl180, ImageSize → 400, PlotRange → All, AxesLabel → {"nth CNC", None},
  LabelStyle → {FontFamily → "Arial", FontSize → 15, Black},
  GridLines → {{100}, {180}}, AxesOrigin → {0, 0},
  PlotLabel → "CNC angles w.r.t. Y-axis"] (* Supplementary Figure 8e *) ,
ListPlot[ψy, ImageSize → 400, PlotRange → All,
  LabelStyle → {FontFamily → "Arial", FontSize → 15, Black},
  AxesLabel → {"nth CNC", None}, PlotLabel → "Pol. direction w.r.t. Y-axis",
  GridLines → {{100}, None}] (* Supplementary Figure 8f *) ,
ListPlot[Etot, ImageSize → 400, PlotRange → All,
  LabelStyle → {FontFamily → "Arial", FontSize → 15, Black},
  AxesLabel → {"nth CNC", None}, PlotLabel → "|Etotal|", GridLines → {{100}, None}],
ListPlot[(dψ), ImageSize → 400, PlotRange → All, LabelStyle →
  {FontFamily → "Arial", FontSize → 15, Black}, AxesLabel → {"nth CNC", None},
  PlotLabel → "Rotation (ψ-ψ0)", GridLines → {{100}, None}]]
{ListPlot[φbtn, ImageSize → 400, LabelStyle →
  {FontFamily → "Arial", FontSize → 15, Black}, AxesLabel → {"nth CNC", None},
  PlotLabel → "Pol. direction w.r.t. CNC normal (before)",
  GridLines → {{100}, None}],
ListPlot[ψres, ImageSize → 400, LabelStyle →
  {FontFamily → "Arial", FontSize → 15, Black}, AxesLabel → {"nth CNC", None},
  PlotLabel → "Pol. direction w.r.t. CNC normal (after)",
  GridLines → {{100}, None}]]



```

```
Print["Etotal after 100th CNC=", Etot[[n+1]]]
```

```
Print["Final intensity after the 2nd polarizer=", PI]
```







E_{total} after 100th CNC= $0.994861 + 0.i$

Final intensity after the 2nd polarizer= $0.742347 + 0.i$

Check numbers after each CNC

2) Random

Storage

Loop

```

In[ ]:= For[p = 1, p < n + 1, p++,

  ϕbtn[[p]] = ψy[[p]] - ϕra180Norm[[p]]; (* convert axis: From y-axis to CNC normal *)
  ψres[[p]] = ψ[ϕbtn[[p]]]; (* result of rotation in CNC normal axis*)
  ψy[[p + 1]] = ψres[[p]] + ϕra180Norm[[p]];
  (* back to y-axis system*) (*F180 is for *)

  dψ[[p]] = ψres[[p]] - ϕbtn[[p]]; (* (ψafter - ψbefore) in CNC axis *)

  ttot[[p]] = tt[ϕbtn[[p]]];
  Etot[[p + 1]] = Etot[[p]] * ttot[[p]]; (* energy loss as passing through *)

  dψ2[[p]] = ψy[[p + 1]] - ψy[[p]];
  (* (ψafter - ψbefore) in CNC axis. How much rotation @ each CNC*)
]
PI = (Etot[[n + 1]] * Sin[(ψy[[n + 1]] - ϕ1) *  $\frac{\pi}{180}$ ])2; (* I = (|Etotal| * sinψ)2 - Equation 5 *)

```

Check plots and final intensity



```




In[ ]:= {ListPlot[φra180, ImageSize → 400, PlotRange → All, AxesLabel → {"nth CNC", None},
  LabelStyle → {FontFamily → "Arial", FontSize → 15, Black},
  GridLines → {{100}, {180}}, AxesOrigin → {0, 0},
  PlotLabel → "CNC angles w.r.t. y-axis"],
ListPlot[ψy, ImageSize → 400, PlotRange → All, LabelStyle →
  {FontFamily → "Arial", FontSize → 15, Black}, AxesLabel → {"nth CNC", None},
  PlotLabel → "Pol. direction w.r.t. y-axis", GridLines → {{100}, None}],
ListPlot[Etot, ImageSize → 400, PlotRange → All,
  LabelStyle → {FontFamily → "Arial", FontSize → 15, Black},
  AxesLabel → {"nth CNC", None}, PlotLabel → "|Etotal|", GridLines → {{100}, None}],
ListPlot[(dψ), ImageSize → 400, PlotRange → All, LabelStyle →
  {FontFamily → "Arial", FontSize → 15, Black}, AxesLabel → {"nth CNC", None},
  PlotLabel → "Pol. rotation", GridLines → {{100}, None}]]
{ListPlot[φbtn, ImageSize → 400, LabelStyle →
  {FontFamily → "Arial", FontSize → 15, Black}, AxesLabel → {"nth CNC", None},
  PlotLabel → "Pol. direction w.r.t. CNC normal (before)",
  GridLines → {{100}, None}],
ListPlot[ψres, ImageSize → 400, LabelStyle →
  {FontFamily → "Arial", FontSize → 15, Black}, AxesLabel → {"nth CNC", None},
  PlotLabel → "Pol. direction w.r.t. CNC normal (after)",
  GridLines → {{100}, None}]]



```

```
Print["Etotal after 100th CNC=", Etot[[n+1]]]
```

```
Print["Final intensity after the 2nd polarizer=", PI]
```







$E_{total} \text{ after } 100th \text{ CNC} = 0.994844 + 0.i$

Final intensity after the 2nd polarizer = $0.742141 + 0.i$

Check numbers after each CNC

3) Helicoidal

Storage

Loop

```

In[ ]:= For[p = 1, p < n + 1, p++,

  ϕbtn[[p]] = ψy[[p]] - ϕhe180Norm[[p]]; (* convert axis: From y-axis to CNC normal *)
  ψres[[p]] = ψ[ϕbtn[[p]]]; (* result of rotation in CNC normal axis*)
  ψy[[p + 1]] = ψres[[p]] + ϕhe180Norm[[p]];
  (* back to y-axis system*) (*F180 is for *)

  dψ[[p]] = ψres[[p]] - ϕbtn[[p]]; (* (ψafter - ψbefore) in CNC axis *)

  ttot[[p]] = tt[ϕbtn[[p]]];
  Etot[[p + 1]] = Etot[[p]] * ttot[[p]]; (* energy loss as passing through *)

  dψ2[[p]] = ψy[[p + 1]] - ψy[[p]];
  (* (ψafter - ψbefore) in CNC axis. How much rotation @ each CNC*)
]
PI = (Etot[[n + 1]] * Sin[(ψy[[n + 1]] - ϕ1) *  $\frac{\pi}{180}$ ])2; (* I = (|Etotal| * sinψ)2 - Equation 5 *)

```

Check plots and final intensity



```




In[ ]:= {ListPlot[phi180, ImageSize -> 400, PlotRange -> All, AxesLabel -> {"nth CNC", None},
  LabelStyle -> {FontFamily -> "Arial", FontSize -> 15, Black},
  GridLines -> {{100}, {180}}, AxesOrigin -> {0, 0},
  PlotLabel -> "CNC angles w.r.t. y-axis",
ListPlot[psi, ImageSize -> 400, PlotRange -> All, LabelStyle ->
  {FontFamily -> "Arial", FontSize -> 15, Black}, AxesLabel -> {"nth CNC", None},
  PlotLabel -> "Pol. direction w.r.t. y-axis", GridLines -> {{100}, None}],
ListPlot[Etot, ImageSize -> 400, PlotRange -> All,
  LabelStyle -> {FontFamily -> "Arial", FontSize -> 15, Black},
  AxesLabel -> {"nth CNC", None}, PlotLabel -> "|Etotal|", GridLines -> {{100}, None}],
ListPlot[(dpsi), ImageSize -> 400, PlotRange -> All, LabelStyle ->
  {FontFamily -> "Arial", FontSize -> 15, Black}, AxesLabel -> {"nth CNC", None},
  PlotLabel -> "Pol. rotation", GridLines -> {{100}, None}]]
{ListPlot[phbtn, ImageSize -> 400, LabelStyle ->
  {FontFamily -> "Arial", FontSize -> 15, Black}, AxesLabel -> {"nth CNC", None},
  PlotLabel -> "Pol. direction w.r.t. CNC normal (before)",
  GridLines -> {{100}, None}],
ListPlot[psires, ImageSize -> 400, LabelStyle ->
  {FontFamily -> "Arial", FontSize -> 15, Black}, AxesLabel -> {"nth CNC", None},
  PlotLabel -> "Pol. direction w.r.t. CNC normal (after)",
  GridLines -> {{100}, None}]]



```

```
Print["Etotal after 100th CNC=", Etot[[n+1]]]
```

```
Print["Final intensity after the 2nd polarizer=", PI]
```







$E_{total} \text{ after } 100th \text{ CNC} = 0.994863 + 0.i$

Final intensity after the 2nd polarizer = $0.742228 + 0.i$

Check numbers after each CNC

4) Uniaxial

Storage

Loop

```

In[ ]:= For[p = 1, p < n + 1, p++,

  ϕbtn[[p]] = ψy[[p]] - ϕun180Norm[[p]]; (* convert axis: From y-axis to CNC normal *)
  ψres[[p]] = ψ[ϕbtn[[p]]]; (* result of rotation in CNC normal axis*)
  ψy[[p + 1]] = ψres[[p]] + ϕun180Norm[[p]];
  (* back to y-axis system*) (*F180 is for *)

  dψ[[p]] = ψres[[p]] - ϕbtn[[p]]; (* (ψafter - ψbefore) in CNC axis *)

  ttot[[p]] = tt[ϕbtn[[p]]];
  Etot[[p + 1]] = Etot[[p]] * ttot[[p]]; (* energy loss as passing through *)

  dψ2[[p]] = ψy[[p + 1]] - ψy[[p]];
  (* (ψafter - ψbefore) in CNC axis. How much rotation @ each CNC*)

]

```

$$PI = \left(Etot[[n + 1]] * \sin \left[(\psi y[[n + 1]] - \phi 1) * \frac{\pi}{180} \right] \right)^2; \quad (* I = (|E_{total}| * \sin \psi)^2 - \text{Equation 5} *)$$

Check plots and final intensity



```




In[ ]:= {ListPlot[φun180, ImageSize → 400, PlotRange → All, AxesLabel → {"nth CNC", None},
  LabelStyle → {FontFamily → "Arial", FontSize → 15, Black},
  GridLines → {{100}, {180}}, AxesOrigin → {0, 0},
  PlotLabel → "CNC angles w.r.t. y-axis"],
ListPlot[ψy, ImageSize → 400, PlotRange → All, LabelStyle →
  {FontFamily → "Arial", FontSize → 15, Black}, AxesLabel → {"nth CNC", None},
  PlotLabel → "Pol. direction w.r.t. y-axis", GridLines → {{100}, None}],
ListPlot[Etot, ImageSize → 400, PlotRange → All,
  LabelStyle → {FontFamily → "Arial", FontSize → 15, Black},
  AxesLabel → {"nth CNC", None}, PlotLabel → "|Etotal|", GridLines → {{100}, None}],
ListPlot[(dψ), ImageSize → 400, PlotRange → All, LabelStyle →
  {FontFamily → "Arial", FontSize → 15, Black}, AxesLabel → {"nth CNC", None},
  PlotLabel → "Pol. rotation", GridLines → {{100}, None}]]
{ListPlot[φbtn, ImageSize → 400, LabelStyle →
  {FontFamily → "Arial", FontSize → 15, Black}, AxesLabel → {"nth CNC", None},
  PlotLabel → "Pol. direction w.r.t. CNC normal (before)",
  GridLines → {{100}, None}],
ListPlot[ψres, ImageSize → 400, LabelStyle →
  {FontFamily → "Arial", FontSize → 15, Black}, AxesLabel → {"nth CNC", None},
  PlotLabel → "Pol. direction w.r.t. CNC normal (after)",
  GridLines → {{100}, None}]]



```

```
Print["Etotal after 100th CNC=", Etot[[n+1]]]
```

```
Print["Final intensity after the 2nd polarizer=", PI]
```







E_{total} after 100th CNC= $0.997945 + 0.i$

Final intensity after the 2nd polarizer= $0.746864 + 0.i$

Check numbers after each CNC

5) Bimodal

Storage

Loop

Check plots and final intensity


```


In[ ]:= {ListPlot[phi180, ImageSize -> 400, PlotRange -> All, AxesLabel -> {"nth CNC", None},
  LabelStyle -> {FontFamily -> "Arial", FontSize -> 15, Black},
  GridLines -> {{100}, {180}}, AxesOrigin -> {0, 0},
  PlotLabel -> "CNC angles w.r.t. y-axis"],
ListPlot[psi, ImageSize -> 400, PlotRange -> All, LabelStyle ->
  {FontFamily -> "Arial", FontSize -> 15, Black}, AxesLabel -> {"nth CNC", None},
  PlotLabel -> "Pol. direction w.r.t. y-axis", GridLines -> {{100}, None}],
ListPlot[Etot, ImageSize -> 400, PlotRange -> All,
  LabelStyle -> {FontFamily -> "Arial", FontSize -> 15, Black},
  AxesLabel -> {"nth CNC", None}, PlotLabel -> "|Etotal|", GridLines -> {{100}, None}],
ListPlot[(dpsi), ImageSize -> 400, PlotRange -> All, LabelStyle ->
  {FontFamily -> "Arial", FontSize -> 15, Black}, AxesLabel -> {"nth CNC", None},
  PlotLabel -> "Pol. rotation", GridLines -> {{100}, None}]}
{ListPlot[phibtn, ImageSize -> 400, LabelStyle ->
  {FontFamily -> "Arial", FontSize -> 15, Black}, AxesLabel -> {"nth CNC", None},
  PlotLabel -> "Pol. direction w.r.t. CNC normal (before)",
  GridLines -> {{100}, None}],
ListPlot[psires, ImageSize -> 400, LabelStyle ->
  {FontFamily -> "Arial", FontSize -> 15, Black}, AxesLabel -> {"nth CNC", None},
  PlotLabel -> "Pol. direction w.r.t. CNC normal (after)",
  GridLines -> {{100}, None}]}



```

```
Print["Etotal after 100th CNC=", Etot[[n+1]]]
```

```
Print["Final intensity after the 2nd polarizer=", PI]
```







E_{total} after 100th CNC= $0.994458 + 0.i$

Final intensity after the 2nd polarizer= $0.741886 + 0.i$

Check numbers after each CNC

G. Final intensity as a function of the incident polarization angle

Note: the same calculation with various incident polarization angle (no explanation included). Data exportation included.



Loop

Plot check

```

In[ ]:= (* Check plots *)
{ListPlot[{clAng, raAng, heAng, unAng, biAng},
  PlotStyle → {{Darker[Green], Thickness[0.008]}, {Red, Thickness[0.008]}, {Blue,
    Thickness[0.008]}, {Black, Thickness[0.008]}, {Orange, Thickness[0.008]}}},
  Ticks → {Table[30 i, {i, 0, 6}], Automatic}, PlotRange → All,
  ImageSize → 500, AxesLabel → {" Azimuth angle (°)", None},
  LabelStyle → {FontFamily → "Arial", FontSize → 15, Black},
  PlotLabel → Style["Intensity", 20, Black, Bold], Joined → True,
  PlotLegends → {"Crossed", "Random", "Helicoidal", "Uniaxial", "Bimodal"}],
ListPlot[{clAng, raAng, heAng, unAng, biAng},
  PlotStyle → {{Darker[Green], Thickness[0.008]}, {Red, Thickness[0.008]}, {Blue,
    Thickness[0.008]}, {Black, Thickness[0.008]}, {Orange, Thickness[0.008]}}},
  Ticks → {Table[30 i, {i, 0, 6}], Automatic}, PlotRange → {All, {0,  $5 \times 10^{-7}$ }},
  ImageSize → 500, AxesLabel → {" Azimuth angle (°)", None},
  LabelStyle → {FontFamily → "Arial", FontSize → 15, Black},
  PlotLabel → Style["Intensity", 20, Black, Bold], Joined → True,
  PlotLegends → {"Crossed", "Random", "Helicoidal", "Uniaxial", "Bimodal"}}]

```

H. Data export

```

In[ ]:= (* Combine generated data *)
clAng2 = Transpose[clAng];
raAng2 = Transpose[raAng];
heAng2 = Transpose[heAng];
unAng2 = Transpose[unAng];
biAng2 = Transpose[biAng];
b1 = {clAng2[[1]], clAng2[[2]], raAng2[[2]], heAng2[[2]], unAng2[[2]], biAng2[[2]]};
b1 = Abs[b1];
b1 = b1 // Transpose;
b1 // MatrixForm;
b1 = PrependTo[b1, {"wavenumber", "crossed-polylamellate",
  "random", "helicoideal10", "uniaxial", "bimodal"}];

(* Data exportation *)
name = CurrentValue[EvaluationNotebook[], {"NotebookFileName"}];
name = StringDrop[name, -3];
time = TextString[TimeObject[]];
time2 = ToExpression["StringTake[time,2]" <>
  ToString["."] <> ToExpression["StringTake[time,{4,5}]" <>
  ToString["."] <> ToExpression["StringTake[time,-2]"
Export[NotebookDirectory[] <> ToExpression["name"] <>
  ToExpression["time2"] <> ToString["_"] <> "CRHUB.xlsx", b1];

Out[ ]:= 15.18.50

```